

GETTING STARTED

The following items are required for installation and operation:

- ▣ USB keyboard /standard keyboard (not included in the delivery)
- ▣ Power connection with two power sockets
- ▣ Internet connection (LAN, WiFi)
- ▣ Screw anchors and screws to mount the display on a wall (not included in the delivery)

The following components are included in the delivery:

- ✓ Solarfox Display / Solarfox Display Kit
- ✓ Solarfox computer controller (mounted on the rear side of the display)
- ✓ Wall mounts and wall panel (already mounted on the display)
- ✓ Solarfox installation instructions/getting started brochure
- ✓ Power supply unit for the Solarfox computer controller
- ✓ LG accessories
- ✓ Network cable (LAN)



DISPLAY INSTALLATION IN FIVE STEPS



1. DEVICE REGISTRATION/USER ACCOUNT REGISTRATION

You need to visit <http://setup.solar-fox.com> to register a Solarfox user account before mounting your Solarfox display. Select your preferred language, enter the serial number of your Solarfox display, and select the data logger you would like to register. Follow the steps to complete the registration process. You can register prior to installation from your office or work computer. **Note:** The data logger/monitoring system must already be set up and data must already be transferred to the Internet. The Solarfox account cannot be activated if this is not the case.



2. MOUNTING THE SOLARFOX DISPLAY

Remove the wall mount panel from the display carriers with a screwdriver and mount the wall mount panel on the desired wall using suitable screws and screw anchors. If possible, use a level to ensure the wall mount panel is straight. Hang the display on the wall panel you have just mounted and secure it using the appropriate screws.



3. CONNECT CABLES AND CHECK THE FUNCTION

Make sure the cables included in the delivery are installed correctly. The Solarfox display must be supplied with power via the power connector cable (230 V). The Solarfox computer controller must be supplied with power via the power supply unit. It is also necessary to connect the LAN cable or the Wi-Fi antenna to the computer controller.



4. DISPLAY SETUP/SETUP ASSISTANT

Switch on the display and connect a USB keyboard to the Solarfox computer controller. The Setup Menu automatically appears on the display. If a 'No Signal' message appears on the display, check to ensure that 'HDMI' was selected as the signal input. Moreover, check the HDMI connection from the display to the computer controller. Select your preferred language in the Setup Menu.

Select 'Setup Assistant' and then select a connection to the Internet. Step 5 prompts you to enter your display code and password. Enter the access data you received via e-mail from Solarfox after your account was activated. The next step allows you to check your details. Step 6 runs a connection test. If any problems occur during the connection test, visit <http://www.solar-fox.com/support.html> for detailed information.



5. SCHEDULED RESTART AND FIRMWARE UPDATE

Make sure the device has the latest firmware: 'Update' → 'Check for updates.'

You have now completely set up the device on site. You can configure the content and layout with your Web browser.



THE SOLARFOX DISPLAY IS NOW READY FOR USE

EN

DE

FR

IT

ES

NL

SE

PT

PL

DK

RU

TR